



# INSTRUCTIONS

BULLETIN 947915B

## TWO-WAY PUMP SUCTION & RETURN VALVES (CHECK VALVE TYPES) FOR OILGEAR TYPE "D" UNITS

### REFERENCE BULLETINS

Type "D" Variable Delivery Pumps-----947000

#### I. CONSTRUCTION.

Check type suction valves are built in two similar styles. The plain type built for size 4 thru 150 units incorporates a single suction check valve (209) and two return check valves (201). The dual type incorporates dual suction check valves (209) and two smaller return check valves (201). Plain type suction valves have a single suction pipe connected to port 5, dual suction valves use pipes connected to ports 16 and 17. Both valves contain a back pressure relief valve (214) (BPRV) enclosed in body (200) and flange (212).

#### II. PRINCIPLE OF OPERATION.

**A. PLAIN.** (Circuit shown in bulletin 947000). Supercharge pressure is generally ported from the gear pump to port 22 of the suction valve. The suction check valve (209) retains supercharge and high pressure relief valve exhaust in the suction valve and pump, yet the pump is allowed to draw fluid from the reservoir thru pipe in port 5 if the supercharge volume is insufficient. The back pressure relief valve (214) limits supercharge or exhaust pressure. Return check valves (201) direct all return fluid thru the pump or to the pumps high pressure relief valves, providing a closed non-differential system. If return volume is insufficient, the return checks open on suction side allowing direct suction or supercharging of that side of the pump.

**B. TWIN.** Supercharge pressure is generally ported from the gear pump to port 22 of the suction valve. The suction check valves (209) retain supercharge, high pressure relief valve exhaust and return fluid in the suction valve and pump, yet allow the pump to draw fluid from the reservoir if supercharge of return

volume is insufficient. The backpressure relief valve (214) limits supercharge or exhaust pressure. Return check valves (201) direct all return flow thru the pump or high pressure relief valves, providing a closed non-differential system. If return volume is insufficient, the return checks allow supercharge fluid to enter suction side of pump.

**C. SPECIAL.** Some pumps are equipped with modified suction valves for specific applications. Some one-way pumps are equipped with a two-way check type suction valve from which one of the return check valves (201) have been removed to eliminate hydrodynamic braking at the high pressure relief valve setting.

#### III. SPECIFICATIONS.

Back pressure relief valves are normally set at 60 psi.

**A.** Approximate pressure variation for each 1/16" shim.

**B.** Maximum total thickness of all shims permitted.

Pump Size	A	B
2 & 4	8	5/8
8 & 12	8	9/16
20	4	1/4
35	4	7/16
60, 100 & 150	4	1/8

#### IV. MALFUNCTIONS AND CAUSES.

Excessive noise in pump is usually caused by air entering system at suction valve gaskets or pipes. Be sure bolts and pipe are tight. It may also be

(Continued on page 4)




Figure 1. Schematic, Twin Suction Check Valve. (3V-10066-L).

IX. PARTS LIST

Part No.	Description	Part No.	Description
200.	Body, Valve	217.	Seal, BPRV
200A.	Screw, Sock. Hd. Cap	218.	Cap, BPRV
201.	Disc, Return Check	218A.	Screw, Sock. Hd. Cap
202.	Seal, Gasket or O'ring	219.	Spring, Ret. Check
203.	Gasket, Spacer	220.	Spring, Suct. Check
204.	Spacer, Seal	221.	Retainer, Seal
205.	Seat, Return Check	222.	Seal, O'ring
206.	Cage, Return Check	223.	Gasket, Body
208.	Cage, Suct. Check	227.	Plug, Pipe
209.	Disc, Suct. Check	228.	Plug, Pipe
210.	Seat, Suct. Check	229.	Assembly, Seal w/retainer
211.	Gasket, Suction Flange	230.	Seal, O'ring
212.	Flange, Suct. Check	231.	Shims, Retainer
212A.	Screw, Sock. Hd. Cap	232.	Seal, O'ring
212B.	Wire, Lock	233.	Cover, Core
214.	Plunger, BPRV	233A.	Screw, Sock. Hd. Cap
215.	Spring, BPRV	234.	Flange, Pipe
216.	Shims, BPRV	234A.	Screw, Sock. Hd. Cap

Parts used in this assembly are per Oilgear specifications. Use Oilgear supplied parts to insure compatibility with assembly requirements. When ordering replacement parts, be sure to include pump serial number, bulletin number and part number. When ordering seals, specify type of hydraulic fluid used.

O-RING SIZES

Cross Section x O.D. Duro ± 5

Part No.	Size Unit								
	4-8-12	20		35		60-100-150 Plain		60-100-150 Twin	
202.	-	3/16 x 2-5/8	90	3/16 x 2-7/8	90	3/16 x 3-5/8	90	3/16 x 4	90
211.	-	-	-	1/8 x 3-1/8	90	-	-	3/16 x 4-3/8	90
217.	-	1/8 x 1-7/16	90	1/8 x 1-7/16	90	-	-	1/8 x 1-1/2	90
222.	-	1/8 x 3	90	3/16 x 3-7/8	70	1/8 x 4-5/8	70	1/8 x 4-5/8	70
-	-	-	-	-	-	-	-	-	-
230.	-	-	-	-	-	-	-	3/16 x 2-1/2	90
232.	-	-	-	-	-	-	-	3/16 x 3-3/8	70




Figure 2. Parts Drawing, Two-Way Suction and Return Valves. DS-947915A (504364-A)

caused by cavitation due to restricted passages or low back pressure. Low back pressure is usually caused by a sticky BPRV plunger (214) or faulty suction check valve (209). Insufficient pump volume or pressure may be caused by excessive leakage past the return check valves (201) or two suction check valves (209) on twin type.

#### V. TESTING AND ADJUSTING.

To check the back pressure relief valve setting, insert a low pressure gage in port 12 and run the pump at neutral. If port 12 is being used, disconnect piping and insert a tee fitting. Connect piping to two legs of the tee and gage to the other. Gage will read the back pressure.

To adjust back pressure, remove inspection cover on side of reservoir (it may be necessary to drain some fluid first). If reservoir base does not have an inspection cover, it will be necessary to disconnect the pump from the circuit and drive motor to raise it so the BPRV can be shimmed. Remove cover (218) over BPRV and add shims (216) to increase pressure, remove shims to decrease pressure. See III. A and B. CAUTION: Do not install solid shims (216) between plunger (214) and spring (215).\*

#### VI. DISASSEMBLY.

Tag all O'rings, gaskets, seals and shims so they will be returned to their original positions. Remove all piping from valve and valve from pump.

Suction Check Valve. Remove suction flange (212). The check valve cage (208) has a 0.002" press fit in suction flange. Complete disassembly of flange and cage is usually not necessary for inspection and cleaning.

Return Check Valves. When suction valve body (200) is removed from pump case (or flange (212) from body (200), for twin type) the return check valve assemblies are exposed. The cages (206), springs (219) and disks (201) are free to be removed. Check valve seat (205) has a 0.002" press fit into body and should not be removed unless cracked or scored.

Back Pressure Relief Valve (BPRV). Remove cover (plug or cap) (218). The shims (216), spring (215) and plunger (214) are free to be removed. Plunger is tapped so a threaded rod can be inserted to withdraw it.

#### VII. INSPECTION.

Check Valves. Check for dirt on the check valve seats (205 & 210) or disks (201 & 209) and examine surfaces for scratches or grooves. Check for cracked seat.

Back Pressure Relief Valve. Inspect valve plunger seat for scoring or foreign matter. Clean V-slot in plunger. Polish or lap sticky plunger. Clearance between plunger and valve body should be 0.001" at both diameters. Be sure hole thru plunger is not blocked.

#### VIII. ASSEMBLY.

Anneal all copper gaskets. Clean all parts thoroughly. If BPRV plunger was lapped, make certain all compound has been removed. Insert BPRV plunger (214), spring (215), shims (216) and secure cover (218).\* Insert suction check valve seat (210) and disk (209), and press cage (208) into suction flange (212). If return check valve assemblies in twin type valves were removed, reassemble in body (200). Mount suction flange assembly with seal (211) on valve body (200). Draw bolts up evenly and very tightly. Insert return check valves assemblies (plain type) valve body (200) and bolt entire suction valve assembly with seals or gaskets, spacers; spacer seals in place on bottom of pump. Draw suction valve mounting bolts up evenly and very tightly as all seals must be air tight. Install suction and exhaust pipes. Use pipe compounds sparingly or Teflon tape and only on male threads, connections must be tight. Connect piping to port 22 and remount pump on reservoir.

\*If a flange type BPRV cover is used, insert hollow shims or washers between plunger and spring and secure cover screws with soft iron locking wire.